



**ER2302 Main power Relay**


Main power relay ON e.g from door switch




FUSE 30A

Battery

Main power relay ON e.g from ignition key (+15) information



**C1 ED1314 IO-Module**



Main power relay OFF

**Esplit44 CAN bus splitter**



**D1 ED28 2.8" Kosketusnäyttö**

